Los Alamos National Laboratory Environmental Restoration Program Standard Operating Procedure

No: LANL-ER-SOP-09.01

Rev: 0

Thin Section Preparation

Preparer:	DAVID A. MANA (Print Name)	(Signature)	9-5-91 (Date)
Quality Review by:	DAVID BROXTEN (Print Name)	Quad Bruthn (Signature)	9/5/41 (Date)
Technical Review by:	A.W. Laugh /, N (Print Name)	An Laughlan (Signature)	9/5/9/ (Date)
Technical Review by:	Anthony R. Griegs (Print Name)	S Anthony R. Grieges (Signature)	(Date)
QPPL Approval:	Karen L. Foster (Print Name)	Karen & Laster (Signature)	<u>////9/</u> (Bate)
PM Approval:	Robert W Vocke (Print Name)	Robert Works (Signature)	///8/9/ (Date)
	Effective Date: 3-16-9	2_	

THIN SECTION PREPARATION

1.0 PURPOSE

The purpose of this procedure is to document the process for the preparation of thin sections from rock samples. Thin sections are used for geological analysis on the microprobe, various microscopes, and for other geological analysis.

2.0 SCOPE

2.1 Applicability

This procedure covers any geologic thin sections prepared in Earth and Environmental Sciences (EES) Division for the Environmental Restoration program, and it is applicable to all personnel who prepare these sections.

2.2 Training

Any person producing thin sections must receive on-the-job training and must be skilled enough to produce thin sections that are acceptable for the intended use.

3.0 DEFINITIONS

A. Thin sections: For the purpose of this procedure, the term thin section will refer to standard petrographic thin sections, as well as grain mounts and fluid inclusion slides.

4.0 BACKGROUND AND/OR CAUTIONS

Preparation of thin sections requires a fine level of skill which cannot be completely described. Also, even a competent preparer may not always produce useable results. Therefore, the final determination of the quality of a thin section must be made by the requestor who decides if the thin section is suitable for the end use.

Of critical importance to this procedure is the accurate transference of sample identification to the thin sections. Samples are to be locked up during non-working hours. Also, all samples must be in locked storage when they are not being used. After thin sections are produced, the thin sections and all remaining sample material are to be returned to the requestor.

Be sure to refer to the appropriate Material Safety Data Sheet (MSDS) when working with the chemicals listed in Section 5.0, Equipment.

5.0 EQUIPMENT

See Attachment A, Equipment and Supplies Checklist, for a list of equipment required for this procedure.

6.0 PROCEDURE

- A. The requestor submits samples for thin section preparation by completing the thin section request form (Attachment B). The request is entered into the thin-section laboratory log book.
- B. Set samples (pre-numbered in ink) on the table in rows. Mark the sample number in an aluminum dish and on a bag. Use extreme care to mark the sample ID correctly. Set the bag under the rock and place the aluminum dish upside down on top of the rock. Do this for every rock sitting on the table.
- C. At this point it must be decided if the sample needs to be impregnated to aid in its slabbing. This is a subjective decision made by the technician. If not, go on to D.
- 1. If the sample needs to be stabilized by impregnation, place it on top of a cookie sheet covered with aluminum foil.
- 2. Paint the surface of the rock completely with epon 815-diethylene triamine. Make sure the sample ID is still clearly legible. If not, write the ID in lead pencil on a piece of paper and attach the paper to the epoxy surface.
- 3. Allow the epoxy to cure before proceeding (24 hours at room temperature, 30-45 minutes in the oven).
- D. Use appropriate slabbing saw to cut a slab 3/8 to 1/2 in. thick. Set the slab on top of the corresponding aluminum dish and put the excess material in the bag that has been prenumbered. At this point, refer to the worksheet to determine whether to core each sample with the diamond core or cut them to chip size with the diamond saw. Use a round or rectangular slide to find the best area on the sample for the thin section. Trace around the pattern with a marking pen. Thin-sections are prepared in accordance with commonly accepted practices, such as those described in the reference.

7.0 REFERENCES

Logitech Machine System's Technology Manual for Thin Rock Section Production, 20 pp.

8.0 RECORDS

The records produced by this procedure are completed Thin Section Request Forms and entries into the Thin Section Laboratory Logbook.

9.0 ATTACHMENTS

- A. Equipment and Supplies Checklist for Preparation of Thin Sections
- B. Thin Section Request Form.

EQUIPMENT AND SUPPLIES CHECKLIST FOR PREPARATION OF THIN SECTIONS

Small supplies:				
	Aluminum dishes			
	Sample bags			
	Cookie sheet			
	Aluminum foil			
	Round or rectangular slides			
	Indelible marking pen			
	Typewriter correction fluid			
	Lead pencil with eraser			
	12" Forceps			
	One 40-ml beaker, two 600-ml beakers, and two 150-ml beakers			
	Pliers			
	Glass stir rod			
	Clean wipes			
	Tongs			
	Dial-caliper			
	Probe or pick			
	Razor blade			
	Large tweezers			
	"600" Glass plate			
	Staining dish			

EQUIPMENT AND SUPPLIES CHECKLIST FOR THIN SECTION PREPARATION (Continued)

	Rubber suction cup bent at 90 degree angle			
	Back drop mounting plate			
	Microscope cover glass (or cover slips)			
	1-inch round ring mold.			
Large Equipment:				
	Slabbing saw			
	8" or 10" diamond saw			
	Diamond core drill press			
	Oven			
	Vacuum Chamber			
	High- and low-speed lap with 100 mesh plate and 1, 3, 6, 30, 40, and 45 micron plates			
	Hot plate			
	Logitech (LP 30) with 1/4-inch rubber and 1-inch thick piece of foam			
	Dial-o-gram balance with disposo weigh boat			
	Ultrasonic cleaner			
	Air blower			
	Electric engraver			
	Ingram thin-section cutoff saw			
	Ingram grinder			
	Petrographic microscope			
	Dust chaser			

EQUIPMENT AND SUPPLIES CHECKLIST FOR THIN SECTION PREPARATION (Concluded)

Chemicals:				
	Epon 815-diethylene triamine			
	Shell epoxy			
	Buehler epoxy			
	Aluminum oxide (1200 grit)			
	Kerosene			
	Pella oil			
	Silicone carbide (600 grit)			
	Isopropyl or ethyl 190 alcohol			
	Distilled water			
	Sodium-cobaltinitrite powder			
	Isop:opanol			
	Hydrofluoric acid			
	Tap water			
	Barium chloride			
	Methanol (MeOH)			
	Amaranth powder			
	Diamond paste (1, 3, and 6 micron)			
	6 micron diamond spray			
<u></u>	Diamond Polishing Extender (mixture of propolenegycol and isopropanol)			
	Duro Super Glue.			

THIN SECTION REQUEST FORM

LOS ALAMOS NATION ENVIRONMENTAL THIN SECTION RE	RESTORATION	Sheet of				
	Site Work Plan					
Technical Area	Inclusive Sample Identi	ifiers:				
Operable Unit		to				
Signature:	D	ate:				
Date Submitted	Priority (check 1 D 3 D	ay ays				
Number of Samples		/eeks nce Available				
() () () () () ()	s Round	Epoxy Casting Probe Standard				
II. THICKNESS REQUIRED (check one): Unlimited 150		7 — ^{30 µ}				
None. Polished on Bottom Side	Polished on Top Side,	Polished on Both Sides				
IV. SPECIAL INSTRUCTIONS	FOR MASTER					
	75750					
		<u> </u>				
V. SAMPLE NUMBER	-	RMS				
SAMPLE LOG SHEET						
Samples received in Sample Prep Lab						
Samples distributed to	Signature	Date				
☐ CHECK HERE IF INFORMATION IS RECORDED ON BACK OF FORM	Signature	Date ER-SOP-08.01, Ro. 4/91				